

Auxiliary Tools for Torque Wrench

Adjusting Tool for QLE

This tool is used to set the torque of the large QLE adjustable wrenches.



Catalog No.	Applicable Models
301	QLE550N ~ 2100N / CLE

Thrusting Tool for SP

This tool is used to set the torque of preset types SP, RSP, QSP, and CSP torque wrenches.



Catalog No.	Tool No.	Applicable Models
310	A-1	QSP1.5N ~ 6N / SP
311	A-2	SP2N ~ 19N, QSP12N / CSP BQSP25N / BCSP
312	A-3	SP38N, 67N BQSP50N ~ 140N / BCSP
313	A-4	SP120N ~ 310N BQSP200N, 280N / BCSP
314	A-5	QSP420N / CSP BQSP420N / BCSP
315	A-6	SP420N, 560N

Adjusting Tools For QSP3



Catalog No.	Dimension [mm]	Applicable Models
931	2.5 x 1.5 x 6	QSP25N3 / CSP
930	4 x 2.5 x 8	QSP50N3 ~ 280N3 / CSP

Carrying Case

One piece of torque wrench and sockets can be packed.



Catalog No.	Dimension [mm]	Weight [kg]	Applicable Models
840	H91 x W429 X120	0.5	QL25N ~ 140N / PQL MTQL70N, 140N DB25N ! 100N Approx. 5pcs of socket (under W19)

Tool Set for DB

This set of pliers is used to set the torque for dial type torque wrenches and torque checkers.



Catalog No.	Applicable Models
316	DB, DBE, T, DOT

DA Down Adapter

Compact adapter to reduce the size of square drive.



Model	Catalog No.	Dimension [mm]				Capacity [N.m]	Weight [g]	Applicable Models
		Square (Male)	Square (Female)	Height	Outer Dia.			
DA3-2	296	9.53	6.35	12	13	50	5	TTC, DOTE, DOT, TF, LC
DA4-3	297	12.7	9.53	15	18	200	11	
DA6-4	298	19.05	12.7	19	28	750	34	
DA8-6	299	25.4	19.05	26	35	2100	696	
DA12-8	300	38.1	25.4	44	55	3000	320	

Evertorque - Lubricant for repairing torque products

For repairing of torque wrenches and torque drivers.



Description	Catalog No.	Applications	
		Applicable Models	Applicable Point
Evertorque	830	Click Type Torque Wrench	Thrust Ring: Steel Ball, Scale Piece, Adjusting Screw: Screw
		Click Type Torque Driver	Main Shaft: Toggle Sheet Serration Partcase, Scale Piece: Screw



[Print](#)



[Close](#)