

## DH SQUARE DRIVE



The DH square drive heads are the standard interchangeable head. They are useful when tightening a large number of matching screws with a common torque wrench. It is recommended to keep one set. They are used with sockets.

Model	Applicable Models
DH10D	CL25N / CSP / PCL, YCL12N, 23N CDB25N-S, VF25N, CEM18N2
DH12D	CL50N / CSP / PCL, YCL45N, 70N CDB50N-S, CF50N, CEM45N2, CTA50 / CTA-P / CTB
DH15D	CL50N ~ 140N / CSP/PCL, YCL90N, 140N CDB100N-S, CF100N, CEM90N2, CTA100 / CTA-P / CTB
DH19D	CL200N / CSP / PCL, YCL180N CDB200N-S, CF150N, CEM180N2, CTA200 / CTA-P / CTB
DH22D	CL280N, 420N/CSP, PCL420N, CDB100N-S, 420N-S CF230N, CEM360N2, 500N2, CTA360 ~ 500 / CTAE-P / CTBE

## HH HEX HEAD



The HH hex-head is for hex. Socket head cap screws.

Model	Applicable Models
HH8D	CL1.5N ~ 12N / CSP, CDBF7N-S, 14N-S CSF7N, 14N, CEM9N2
HH10D X 5	CL25N / CSP / PCL, YCL12N, 23N CDB25N-S, VF25N, CEM18N2
HH10D X 6	
HH10D X 8	
HH12D X 5	CL50N / CSP / PCL, YCL45N, 70N CDB50N-S, CF50N, CEM45N2, CTA50 / CTA-P / CTB
HH12D X 6	
HH12D X 8	
HH12D X 10	
HH15D X 8	CL50N ~ 140N / CSP / PCL, YCL90N, 140N CDB100N-S, CF100N, CEM90N2, CTA100 / CTA-P / CTB
HH15D X 10	
HH15D X 12	
HH15D X 14	
HH19D X 10	CL200N / CSP / PCL, YCL180N CDB200N-S, CF150N, CEM180N2, CTA200 / CTA-P / CTB
HH19D X 12	
HH19D X 14	
HH19D X 17	
HH19D X 19	CL280N, 420N / CSP, PCL420N, CDB100N-S, 420N-S CF230N, CEM360N2, 500N2, CTA360 ~ 500 / CTAE-P / CTBE
HH22D X 12	
HH22D X 14	
HH22D X 17	
HH22D X 19	
HH22D X 22	

### NOTE

1. To be used with hex. Key inserted.
2. HH8D is not used with hex. Key but interchangeable bit.


[Print](#)

[Close](#)